

HEX AIR HOSE NIPPLES

For air or many other applications, MS nipples are economical and reusable. The MS nipple accepts bands or clamps. However, each MS is specially designed with a collar behind the hex to engage the gripping fingers of an interlocking clamp. MS threads are NPT. Steel Plated. Use also as companion end of female ground joint.



MS NIPPLE

Hose I.D. (inch)	Thread Size	Part Number
1/4	1/4	MS4-4
1/4	3/8	MS4-6
3/8	1/4	MS6-4
3/8	3/8	MS6-6
3/8	1/2	MS6-8
1/2	1/4	MS8-4
1/2	3/8	MS8-6
1/2	1/2	MS8-8
1/2	3/4	MS8-12
3/4	1/2	MS12-8
3/4	3/4	MS12-12
3/4	1	MS12-16
1	3/4	MS16-12
1	1	MS16-16
1-1/4	1-1/4	MS20-20
1-1/2	1-1/2	MS24-24
2	2	MS32-32
2-1/2	2-1/2	MS40-40
3	3	MS48-48
4	4	MS64-64

TUBE HOSE MENDER

Type SM hose menders repair hose up to and including ID's of 12". After cutting out the damaged hose portion, insert each end of the mender (shanks) into the remaining good ends of the hose. Secure the SM type mender with bands or DB double bolt clamps. Each end will accommodate two or more bands or two clamps for an economical and efficient return to service. Plated Steel.



Hose I.D. (inch)	Part Number
1/2	SM050
3/4	SM075
1	SM100
1-1/4	SM125
1-1/2	SM150
2	SM200
2-1/2	SM250

Hose I.D. (inch)	Part Number
3	SM300
4	SM400
5	SM500
6	SM600
8	SM800
10	SM1000
12	SM1200